

3520 and 3525 TABLE COVERS - CARE AND CLEANING

DO

- Hand wash or spot wash with mild soap to maintain fabric strength and color vibrancy.
- Soak and spray with prewash treatments.
- Let air dry.
- Roll completely dry fabric for storage to keep the material from creasing.
- Lightly steam to remove wrinkles.
- Use light, short and low temperature machine washing and drying settings.

DON'T

- Don't dry clean, which damages the graphics.
- Don't use heavy steaming, which may water-stain and cause materials to lose elasticity.
- Don't use heavy machine washing, which may water-stain and weaken the material.
- Don't iron, which will melt the fabric, and damage the graphics.
- Don't use outdoors in extreme weather, including heat, cold, high winds, heavy rain, hail.

NOTICE

- Fading or wear. Small loose threads or damage to the hem could lead to a larger issue.
- Extreme temperature change can cause the material to stiffen and become brittle.
- Sunlight and heat will eventually to lighten colors.
- Strong winds may strain the material and hem, which could unravel the material.
- Black and cyan inks break down faster under UV light.
- The material comes with a protective coating that comes off during the printing process, but traces may remain on the fabric. The coating will cause a sheen, and it is normal for the material to gradually lose this sheen.
- Polyester is flame resistant, but will melt and smolder under flame and high heat.